

inspiration - Couching designs


- S1437_Swirl_Couching
- 7342_Explore_Couching
- 7342_Jungle_Couching
- 6842_Mandala_Couching
- 7212_Border_Couching

With the Couching function, the thick yarn will be fed from above with the BERNINA Free-Motion Couching foot #43.

Fabric / Notions

- Handicraft yarn
- BERNINA Maxi or Jumbo Hoop
- BERNINA Free-motion couching foot #43

Designs



S1437_Swirl_Couching

1. Embroidery / Couching Layer




7342_Explore_Couching

1. Embroidery / Couching Layer



7342_Jungle_Couching

1. Embroidery / Couching Layer



6842_Mandala_Couching

1-5. Flower_Couching layers

The different colours are only intended as a stopping place for



7212_Border_Couching

1. Embroidery / Couching Color 1
2. Embroidery / Couching Color 2
3. Embroidery / Couching Color 3



Instructions

The cords are fed directly to the needle through a hole in the sole, and can be embroidered on in any direction.

Before using the Free-Motion Couching Foot for the first time, attach the extra guide to the side of machine following the instructions included with the accessory.

Cords which are not too stiff and have a smooth surface structure are suitable for couching with this foot.

Unsuitable are loosely twisted or soft cords, as the needle penetration in the thread is not always guaranteed and the cord cannot be couched properly.

Use it only with a needle size 80Nm.

If an embroidery thread in the same color as the yarn is used, the stitches are hardly visible.

Thread the BERNINA Free-motion couching foot #43 with suitable yarn and attach it.

Reduce the speed and make sure that the yarn can be embroidered unimpededly.

When finished, remove the foot plus cord. Pull the yarn ends to the wrong side of the fabric and tie them to a knot.



This arw projects from the BERNINA inspiration magazine. It provides trendy fashion, beautiful accessories and great décor ideas for upcycling.

For more information visit:
inspiration.bernina.com

